

PRIMING

- When using 15-gallon drums of chemical, remove the 2" plug with a drum bung wrench or two flat head screwdrivers
(hold one vertical while leveraging the other horizontally across the cap)
- For Proxy-Clean® add several ccs of water to the output hose before priming. This helps build head pressure on the pump which will speed up the priming process
(this does not need to be done for the priming of Mineral-Clean™ due to the higher viscosity of the chemical)
- Prime the product into the head of the pump before attaching the output hose to the injection port to avoid priming into pressure

Set the pump to manual mode to prime chemical into the pump. Once chemical is primed into the head of the pump, attach the output hose to the injection port and continue priming until chemical is primed into the lines. Once chemical is primed into the lines, switch the mode on the pump to the X N mode for metered injections (for detailed pump operation, refer to the set-up instructions)

AGROW-CLEAN INSTALLATION DIAGRAM

