

Proxy-Clean® Brand

# Triple-C™

Cool Cell Cleaner

**Triple-C™ Efficiently Removes  
Mineral & Scale Build-Up  
From Cool Cell Pads**

**Equipment Friendly  
with Foaming Action**

## **DIRECTIONS FOR USE:**

### **NORMAL CLEANING of COOL CELL PADS**

1. Allow system to operate until pads are wet
2. Add 1 Quart of Triple-C™ to the recirculation tank
3. Allow system to circulate for 4-6 hours (*Foaming is Normal*)
4. Turn OFF system & rinse pads with fresh water  
(*System can be allowed to sit IDLE overnight & rinsed the next day*)
5. Drain system & refill with fresh water

### **HEAVY CLEANING of COOL CELL PADS UTILIZING the QWIK-FOAM APPLICATOR**

1. Allow system to operate until pads are wet
2. Use Qwik-Foam applicator to foam 1 Quart of Triple-C™ directly onto the Cool Cell Pads
3. Allow system to circulate for 6-8 hours (*Foaming is Normal*)
4. Turn OFF system & rinse pads with fresh water  
(*System can be allowed to sit IDLE overnight & rinsed the next day*)
5. Drain system & refill with fresh water

Manufactured For:  
Proxy-Clean® Products  
McKinney, TX 75071  
[www.proxyclean.com](http://www.proxyclean.com)

FOR INDUSTRIAL USE ONLY

Proxy-Clean® is a Registered Trademark

Net Contents 1 US Quart